

HITCH MOUNTED SWING OUT

INSTALLATION INSTRUCTIONS

YOU'LL NEED THE FOLLOWING TOOLS TO ASSEMBLE AND INSTALL THE EUROWISE HITCH SWING OUT

***LARGE ADJUSTABLE WRENCH (FOR LARGE NUT AND BOLT), 19MM SOCKET,
10 INCH LONG EXTENSION, RATCHET AND A 10MM SOCKET OR WRENCH***



Install the swing out without the A-Frame into the hitch first. This is easier to handle instead of the entire assembly. The bolt inside the hitch insert may need to be loosened to get the hitch to slide in.

Once installed into your vehicles hitch, install the hitch pin thru the desired hole for spacing.

Next tighten the bolt. You can tighten up to 100ft lbs to secure the swing out.

Next you can install the A-Frame. Using the supplied bolt you can feed the bolt into the A-Frame from the top. Use the nut supplied and adjustable wrench to hold one side. Tighten the opposite side. You can tighten them about 100-125lbs. It does not need to be over tightened.

Next you can install the license plate bracket with the 10mm hardware. It may come already installed.

Installing the wheel onto the A-Frame you can leave the washers that hold the 14mm bolts on it. This will help hold the bolts from falling out when installing.



Once the bolt is tightened it will look like this. That will make the swing out tight and not rattle in the hitch

If you have any questions please contact us

info@eurowise.com