EUROWISE TIRE FITMENT GUIDE			
Cayenne/Touareg/Q7: T1/T2/T3/955/957/958 (2004 - 2018)	Modification/Trimming Recommendation	Recommended Lift Size	Intercooler Relocation Recommended
SHOP.EUROWISE.COM			SHOP.EUROWISE.COM
265-65-17	Little to no rubbing	Stock - 2" - 2.5"	NO
255-65-17	Little to no rubbing	Stock - 2" - 2.5"	NO
255-55-18	No trimming	Stock - 2"	NO
265-60-18	No trimming	Stock - 2"	NO
265-65-18	Mild rubbing (heat gun to move plastic)	Stock - 2" - 2.5"	NO
265-70-18 (+25mm Spacers OEM Wheels)	Little to no rubbing	Stock	YES
275-60-18 (Stock Suspension and Wheels)	No trimming	Stock	NO
275-65-18	Rubbing on front and rearward (front wheels)	Stock - 2" - 2.5"	NO
255-60-19 (Stock Suspension and Wheels)	No trimming	Stock	NO
255-55-19	Mild rubbing (heat gun to move plastic)	Stock - 2" - 2.5"	NO
275-55-19 (Stock Suspension and Wheels)	No trimming (T1/T2/955/957; have not confirmed on 958)	Stock	NO
285-60-18 (T1/T2 Only)	Mild rubbing iIntercooler relocation needed if Turbo)	2.5" +	YES
265-50-20	Little to no rubbing	Stock - 2" - 2.5"	NO
SHOP.EUROWISE.COM			SHOP.EUROWISE.COM
255-70-17	Mild to moderate trimming	2 - 2.5"	NO
255-75-17	Mild to moderate trimming	Stock	NO
265-70-18	Mild to moderate trimming	2.5"+	YES
275-70-18	Lots of trimming	2.5"+	YES
285-60-18	Lots of trimming and rocker panel fabrication (Cayenne Only)	3"+	YES
285-65-18	Lots of trimming and rocker panel fabrication (All Models)	3"+	YES
285-70-18	Lots of trimming and rocker panel fabrication	3"+	YES
33-12.50-18	Lots of trimming and rocker panel fabrication	3"+	YES
33x10.50 - 33x12.50	Lots of trimming and rocker panel fabrication	3"+	YES
275-55-20	Trimming required	2 - 3"	YES
33-12.50-20	Lots of trimming and rocker panel fabrication	3"+	YES
285-50-20	Lots of trimming	3"+	YES
SHOP.EUROWISE.COM			SHOP.EUROWISE.COM
	Lots of trimming and rocker panel fabrication		
34 - 35"+	Modification on rear rocker panel	3"++	YES
NOTES:			
Fire brands can affect sizes as each manufacturer make f you are sticking out further you may contact the outsid	s their tires different width and diameter, please take this into account. Spacers a e bumper more than the fender liner or vice versa.	nd wheel offset can also change this.	
T1/T2/955/957 Fabrication requires cutting the rearwar		. We sell these precut plates to weld in pl	ace on our site. Search for "rocker panel plate".
	e fender liner and use a hammer and smash or cut off the pinch weld area on the r		
T1/T2/955/957 Turbo Models, with rear interior heat clin his is a DIY and we do not currently offer any products	mate control has coolant pipes on the drivers side behind fender liner that need to for this.	be relocated when trying to run bigger th	an 33" tires.